



S-Lock

S-Series

for Harris Bipods

We sell our own line of adapters and combos custom designed
& manufactured to fit Harris Engineering bipods.



INSTALLATION + INSTRUCTIONS



Always ensure that your firearm
is unloaded prior to installation

Harris "S" Series



This allows Harris "S" series bipods to adjust the swivel tension quickly and easily by providing extra torque to adjust and lock the tension.

Harris "S" Series



Picture 1

Remove the nut "A" in the front of the bipod using a 1/4" socket tool.

Tip: Tip- Hold finger over retaining pin opposite of nut "A" throughout removal and installation to prevent the rod and pin from falling out.

Harris "S" Series



Picture 2

Remove nut "B" using fingers to unscrew.

Harris "S" Series



Picture 3



Picture 4

Place S-Lock bushing "C" onto rod. Screw S-Lock lever "D" onto rod. Your new S-Lock is now installed. Tighten the lever just until it locks the swivel action of the bipod.

Note: Do not over tighten; doing so may damage the threaded rod.

THANK YOU

Please visit harrisbipods.com where we sell the complete line of Harris Engineering Bipods and MIM Manufactured adapters at discounted prices.



Take Your Best Shot...



Limited Warranty

Guaranteed forever from date of purchase against defects in materials and workmanship. Guarantee does not extend beyond replacement or repair of adapter. MIM Manufacturing has no control over and assumes no responsibility for manner in which adapters are used. Prices and specifications are subject to change without notice.

- Patent Pending -

1455 Southford Road, Ste K | Southbury, CT | 06488
email: info@mim-mfg.com | www.mim-mfg.com



© 2021 Newford Group